

How to Order *EXOWELD*

It is most important to have the proper and complete material on field to make EXOWELD Connections. Be sure to order the following material and tools as required:

Materials

1. Have the proper mold. Note that the average mold life is 50 connections.
2. Use the correct size EXOWELD Weld Metal. One per connection unless otherwise noted in the catalog.
3. Order lugs, ground plates, etc., if required .

Tools

1. Check for the proper mold handle clamp. Most molds use the CL-3 Change Handle Clamp.
2. Be sure to use a cable cleaning brush.
3. Use a rasp for cleaning steel or cast iron surfaces.
4. A Flint Ignitor is needed with each handle clamp.
5. The Strike-rod is used with Electrical-Striker for bury the ground rod into the earth easily.